



# CARBORUNDUM

## PREMIUM PERFORATED TRIM MASKING TAPE

H<sub>2</sub>O



**One size fits all moldings / Perforated for easy application / Lifting tab on bottom edge for quick removal / Self-dispensing box**

This premium automotive trim masking tape is designed to lift the molding away from the surface to be painted and protect the molding from paint and overspray. Trim tape provides full paint coverage without paint “bridging” to the molding. Eliminate the cost of removing and installing moldings by simply protecting them properly during the painting process.

### One Size Fits All

Premium Trim Masking Tape is designed to lift the molding from the surface to be painted to allow paint coverage under the molding. This tape works well on flush mount windshield, sidelight and back glass moldings. Trim tape is perforated for easy tear-off and is flexible to follow contours and tight curves.

Slide the firm plastic strip under the molding or double fold the strips for greater support on rigid moldings, pull evenly to clear the molding from the surface to be painted, and then press the tape to the glass or panel. A lifting tab allows for the tape to be removed easily after painting. Eliminate the cost of removing and installing moldings, damage to moldings caused by removal and the labor to remove paint lines on existing moldings.

| FEATURES  | BENEFITS  |
|---|---|
| <ul style="list-style-type: none"> <li>Perforated every 40mm (1-1/2")</li> </ul>                  | <ul style="list-style-type: none"> <li>Take just what you need for the job</li> <li>Quick application, no cutting tool needed</li> <li>Work around tight corners easily with individual pieces</li> </ul> |
| <ul style="list-style-type: none"> <li>No Liner</li> </ul>  | <ul style="list-style-type: none"> <li>Quick application</li> <li>No waste to dispose of</li> </ul>   |
| <ul style="list-style-type: none"> <li>Easy Lifting Tab</li> </ul>                                | <ul style="list-style-type: none"> <li>Quick removal</li> </ul>   |
| <ul style="list-style-type: none"> <li>Rubber-based adhesive</li> </ul>                           | <ul style="list-style-type: none"> <li>Superior quick stick</li> <li>Easily removed without adhesive transfer</li> </ul>  |
| <ul style="list-style-type: none"> <li>Saturated crepe paper and durable plastic strip</li> </ul> | <ul style="list-style-type: none"> <li>Resists moisture and solvents</li> <li>No bleed-through</li> <li>Conforms to curved surfaces without lifting or tearing</li> </ul>                                 |
| <ul style="list-style-type: none"> <li>Two plastic strips on the roll (9mm &amp; 11mm)</li> </ul> | <ul style="list-style-type: none"> <li>One size fits all</li> <li>Reduce inventory to one size</li> <li>Can double over for better support on rigid moldings</li> </ul>                                   |

# PREMIUM PERFORATED TRIM TAPE

One size fits all moldings / Perforated for easy application / Lifting tab on bottom edge for quick removal / Self-dispensing box



Trim Masking Tape will withstand a bake cycle up to 250° F (121° C) for 40 minutes.

It can withstand higher temperatures, depending upon the total time, temperature, surfaces masked and other conditions.

Trim Masking Tape should not be subjected to outdoor applications or prolonged periods of sunlight as the tape may become difficult to remove.

| UPC          | SIZE                         | PACKAGING               |
|--------------|------------------------------|-------------------------|
| 055395-99359 | 50mm x 10m (2" x 10.94 yds.) | 1 per pack / 6 per case |

PREMIUM TRIM TAPE



Tear off a small section to mask a tight corner. Using the perforations, tear the tape down to the plastic section and then slide in between the rubber trim and the bodywork.



To mask along a straight section, tear off a piece no longer than eight inches (20cm). Slide it under the molding and pull down evenly. Adhere the tape to the glass so that a small gap is created. Lifting the molding in this way will allow paint to flow under it. Make sure that the next piece of trim tape overlaps the last piece for complete coverage.



Mask as normal and paint.



Allow paint to dry and remove all the masking material.



Check edges and polish with Carbo Finish if necessary.



www.carboauto.com

Saint-Gobain Abrasives, Inc.  
 USA: Telephone 1 877 447-5359  
 Canada: Telephone 1 800 268-2262



CA5543  
 Saint-Gobain Abrasives, Inc. March 2011 • The Carborundum logo is a registered trademark and Carbo Finish is a trademark of Saint-Gobain Abrasives, Inc.

